

NOTE:

1. The pins are very sharp, keep out of the reach of children!
2. To avoid injury, do not point pins at people or animals.
3. Keep unit dry and clean to ensure accuracy.
4. If not in use for a long period of time, remove the battery.
5. Abnormally high readings may be caused by surface salts on newly plastered walls or by contact with metal or steel reinforcing bars etc behind a particular surface.

Sonin Inc.
www.sonin.com
Made in China

- 3 -

Thank you for choosing a Sonin Digital Moisture Meter. Please read this manual before use.


FEATURES:

- Easy to Read Large LCD display with Low Battery Symbol
- Range: 5% to 40%
- Resolution: 1%
- Power: one 9V Battery
- Dimensions: 5" x 2 1/2" x 1 1/4"
- Weight: 4 oz. with battery
- Operating Temperature:
32°F to 104°F (0°C to 40°C) 0-70% RH

- 1 -

DIGITAL MOISTURE METER

OPERATING MANUAL

-  Push upward with thumb to remove probe cover.



FRONT PANEL DESCRIPTIONS

1. Probe Cover
2. Probes
3. Data Hold button
4. Power button
5. LCD display
6. Battery Cover



INSTRUCTIONS FOR USE:

- A. Remove back cover and install one 9V battery, pressing tabs firmly in place.
- B. Remove cover by pressing **UP** upward with your thumb.
- C. Press **P** to power on unit and then insert the pins approximately 1/8" into wood, wallboard, or material to be tested. The moisture content will display on LCD.

WARNING: DO NOT PLUG THE PROBES INTO ANY ELECTRICAL RECEPTACLES.

- D. To HOLD current reading, press **H** button. Press **H** again to cancel or to take next reading.
- E. When finished, turn it off by pressing the **P** button and replace cover on probes.
- F. If a probe is damaged, it can be replaced. The old probe can be taken out by loosening the 5mm nut in a counter-clockwise direction. Remove the old probe and replace with the new probe, then tighten the nut again.

- 2 -