



GFI Receptacle Tester

MAIN FUNCTIONS


TRIPS GFI
RECEPTACLE
TO INDICATE
RECEPTACLE IS
OPERATIONAL


LIGHT PATTERN
INDICATES
CONDITION OF
WIRING



READ INSTRUCTIONS BEFORE USING:

- Consult the GFCI manufacturer's installation instructions to determine that the GFCI is installed in accordance with the manufacturer's specifications.
- Check for correct wiring of receptacle and all remotely connected receptacles on the branch circuit.
- Operate the test button on the GFCI installed in the circuit. The GFCI must trip. If it does not - do not use the circuit - consult an electrician. If the GFCI does trip, reset the GFCI. Then, insert the GFCI tester into the receptacle to be tested.
- Activate the test button on the GFCI tester for a minimum of 6 seconds when testing the GFCI condition. An audible or visible indication on the GFCI tester must cease when tripped.
- If the tester fails to trip the GFCI, it suggests:
 - A wiring problem with a totally operable GFCI, or
 - Proper wiring with a faulty GFCI.Consult with an electrician to check the condition of the wiring and GFCI
- CAUTION:** When testing GFCIs installed in 2-wire systems (no ground wire available), the tester may give a false indication that the GFCI is not functioning properly. If this occurs, recheck the operation of the GFCI using the test and reset buttons. The GFCI button test function will demonstrate proper operation.

CAUTION:

- All appliances or equipment on the circuit being tested should be unplugged to help avoid erroneous readings.
- Not a comprehensive diagnostic instrument but a simple instrument to detect nearly all probable common improper wiring conditions.
- Refer all indicated problems to a qualified electrician.
- Will not indicate quality of ground.
- Will not detect 2 hot wires in circuit.
- Will not detect a combination of defects.
- Will not indicate reversal of grounded and grounding conductors.

SONIN Inc., Charlotte, NC
Phone: (800)225-7511 Website: www.sonin.com
Made in China
© 2011 Sonin Inc.

Model #S0905

OPEN GROUND



Ground
contact not connected

OPEN NEUTRAL



Neutral
contact not connected

OPEN HOT



Hot
contact not connected

HOT/GRD, REVERSE



Hot and
ground
contacts
interchanged

HOT/NEU, REVERSE



Hot and
neutral
contacts
interchanged

CORRECT



Receptacle
wired correctly

- Red is on
- Amber is on
- Light is off